


## Turning On/Off the Screen Rotation Feature

If the screen does not auto-rotate, the auto-rotation setting may be locked in one position. Here's how to unlock it:

1. With the Cover detached, swipe in from the right edge of the screen, or select **Action center** in the taskbar.
2. If **Rotation lock** is undimmed, auto-rotation is locked. Select **Rotation lock** to unlock auto-rotation. *(You will only need to touch the Rotation lock to enable/disable the rotation feature.)*



**Rotation lock** is undimmed when auto-rotation is locked. When **auto-rotation** is locked, the screen won't rotate when you change the orientation of your Surface.



3. Reattach your Surface Typing Cover, fold it back, and check to see if the display rotates automatically when you turn your Surface.